

sikkens
WOOD COATINGS

CARE INSTRUCTIONS

THIS WOODEN WINDOW IS FINISH-COATED

Please cover its surface before plastering

Use only adhesive tapes that are approved for acrylic lacquers.

Approved adhesive tapes*:

3M: Scotch 244 paper adhesive tape
kip: 308 FineLine tape
kip: 810 Duoband
Storch Brand Tape 4931 „The Golden“
Tesa: Surface protection tape 4438 UV

The tapes have to be removed within 2 weeks. (Observe the manufacturer‘s instructions. Do not use sharp tools for doing so.)

* Product-specific changes of the adhesive tapes are reserved.

Ventilation against moisture in the building (risk of paint damage)

Important:

- Heat and ventilate simultaneously in case of cold weather building work.
- Ensure sufficient ventilation for plaster and screed work.
- If condensation forms on the inside of the window, ventilate as quickly as possible.
- Use intermittent airing; do not permanently tilt the window.

Clean only with neutral all-purpose cleaners or Sikkens Wood Coatings special cleaner. Abrasives, acids or aggressive solvent-based cleaners will damage the surface.

Your specialist

Akzo Nobel Wood Coatings GmbH
Sikkens Wood Coatings
Düsseldorfer Straße 96-100
40721 Hilden · Germany
Tel.: +49 (0) 21 03 77 800
Fax: +49 (0) 21 03 77 577
sikkens-holzbau-info@akzonobel.com
www.sikkens-wood-coatings.com

AkzoNobel

AN_201026_240914